



SHINGLEBACK[®] OFF ROAD

DOLLY STAND

Assembly Instruction and Install Booklet





STEP 1. CHECK PARTS AND GATHER TOOLS

- Shifter or 18mm spanner
- 19mm spanner or socket



STEP 2. FIT THE GUSSET PLATES TO THE CROSS BEAM AS SHOWN.

- Nip one bolt up just firm for now





STEP 3. FIT THE ARMS

- **TIP:** insert one bolt then pivot up to line up the second.
- Once all bolts are fitted, tighten all bolts.





STEP 4. FIT THE CASTORS.

TIP: FLIP THE DOLLY UPSIDE DOWN TO FIT THE CASTORS.

- A washer goes under the head of the bolt and under the nut.

Note: When attaching the casters to the dolly, please utilise the four M12 x 80 hex head bolts provided in a separate bag.





STEP 5. FIT THE ORANGE HANDLE

IMPORTANT: APPLY GREASE / ENGINE OIL / CHAIN LUBE TO THE THREAD TO ENSURE SMOOTH OPERATION AND PREVENT RUST.



TIP: LOCK THE CASTORS TO PREVENT MOVING WHILE LOADING BIKES.



Our 10 Year Guarantee. We love our work!

We're so confident in the workmanship of our Shingleback Racks that we're prepared to offer customers a 10 Year Guarantee.

The workmanship guarantee covers:

- Build quality
- Welding
- Breaking or bending of materials (when used in accordance with intended purpose and not overloaded)

If you experience an issue with your rack or accessory, please contact us directly and we will work with you to find a solution.

Excluded from guarantee:

- Damage from misuse of the product, or use against the advice of Shingleback Off Road
- Damage from accidents
- Bungee cord loops and buttons (these will last a long time but they have a limited lifespan)
- Powdercoating (while it is an industrial scratch resistant powdercoat we can't guarantee against it being worn through)
- Anti rattle clamp (Over extended periods of usage this part should be replaced as the U-bolt wears over time – purchase of this part is available on our website)
- Rust
- Stickers

For more information visit shinglebackoffroad.com.au/warranty



SHINGLEBACK® OFF ROAD



10 YEAR GUARANTEE