



WHAT'S INCLUDED

- LH bracket
- RH bracket
- 4 × M8 × 25mm button head bolts
- 4 × M8 washers
- 4 × M8 nyloc nuts



IMPORTANT: Using the Roadie Cradle Tilt Brackets reduces the cradle capacity to 12kg.



PREPARE YOUR SETUP

Lay out all components and identify which cradles you plan to fit with tilt brackets. You will need to remove the **selected cradles from the rack** before installation.

Tip: For improved bike-to-bike clearance, tilt every second cradle.



INSTALL THE BRACKETS

With the cradle removed, attach the LH and RH brackets to the cradle using the supplied bolts, washers, and nyloc nuts.

Ensure all hardware is fitted correctly and tightened securely.



REFIT THE CRADLE

Once both brackets are installed, reattach the cradle to the top bar of your rack.

Tip: Cradles can be rotated in either direction to further improve bike clearance.



FINAL CHECK

When transporting your road bikes, ensure the **bungee loops are tight and secure**. Wrap around the cradle or bottom bar if required (see image).



ANY QUESTIONS?

P: 0494 127 516

E: contact@shinglebackoffroad.com.au

W: www.shinglebackoffroad.com.au

Designed, tested, and manufactured in North East Victoria.

