




CHECK COMPONENTS

Ensure you have all 3 parts:
1 x rear insert (no icon)
1 x front insert (bike icon)
1 x bottom clip


The insert with the larger cut-out and bike icon faces the bike.



INSTALL THE BOTTOM CLIP

Clip the smaller insert into the base of the cradle.

Push firmly until it is **fully seated and secure**.



INSTALL REMAINING INSERTS

Fit the two larger inserts into the cradle as shown.

The insert with the **bike icon** faces **the bike** (outer side), and the insert with **no icon** faces **the vehicle** (inner side).

Push each insert in firmly until it clicks fully into place and sits flush.



LOAD AND SECURE THE BIKE

Place the bike into the cradle and secure the wheel using the orange bungee loops. Ensure the wheel is held firmly in place.

Note: A small gap between the lower clip and tyre may occur depending on wheel size - this is normal.



FINAL CHECK

When transporting your road bikes, ensure the **bungee loops are tight and secure**. Wrap around the cradle or bottom bar if required (see image).



ADJUSTMENT & FIT

You can adjust the position of your cradles to prevent bike-to-bike contact

Tip: If carrying multiple road bikes side by side, we recommend using Roadie Cradle Tilt Brackets (sold separately) to improve clearance.

⚠ IMPORTANT ⚠

1. Inserts only fit Shingleback racks with new cradles; they are **not compatible with Classic racks**.
2. Remove all 3 inserts when not in use.
3. **Do not drive with unloaded inserts**, as they require tyre pressure to stay secure.

ANY QUESTIONS?

P: 0494 127 516

E: contact@shinglebackoffroad.com.au

W: www.shinglebackoffroad.com.au

Designed, tested, and manufactured in North East Victoria.

